



Instructions for Modern Birdhouse Assembly



Step 1: Take the hanger contents out of the packaging. You should have 3 pieces: the hanger, fastener and black rubber stopper.



Step 2: Remove the rubber stopper on the bottom of the birdhouse and set aside.



Step 3: Place the top piece of the birdhouse on top of the body of the birdhouse and make sure the two holes are aligned. Insert unlooped end of wired hanger through the holes. Hold the two ceramic pieces together and carefully flip them over, holding them tightly together while keeping the wire in place. Pull the wire hanger all the way through the piece and out the end. Push the black rubber stopper onto the wire (concave side facing the inside of birdhouse), pushing far enough so you have enough room to loop and fasten the end of the wire.



Step 4: After you add the black rubber stopper, string the metal fastener onto the wire and pull down to the rubber stopper, then loop the end over and insert into the remaining hole of fastener. Make sure you push the wire through the second hole as much as possible so it is secure. Press white rubber stopper back in place at the base of birdhouse.



Step 5: Hang and enjoy!